

# SuperBrace

## THE ULTIMATE FORK BRACE

---

### SuperBrace Part # 2315

---

#### Installation instructions

**Fits Model: Honda Goldwing 1500**

**Years: (1988-2000)**

1. Place motorcycle on center stand (or side stand).
2. Remove the plastic fork seal protector, to expose the four (4) Allen head bolts.
3. Remove one front bolt and the opposite rear bolt.
4. Screw on the two long studs, approximately 1/4" into the fender support plates.
5. Remove the other two bolts and install the SuperBrace, over the studs, and secure it with two of the new bolts using a 7/16 or 11 mm thin wall socket. Remove studs and install other two bolts then tighten all four. Torque to 12 ft. pounds. **NOTE: The SuperBrace should fit snug, but do not force. If the SuperBrace will not seat by tapping with your hand, you may have to file the high spots off the fork casting where it contacts the SuperBrace and/or loosen the axle pinch bolts. Put the SuperBrace into position and then re-tighten the axle pinch bolts to factory specification.**
6. Inside the plastic chrome cover will be two short ears. A pair of pliers will sufficiently break them off, otherwise the cover will not fit properly.
7. Re-install the plastic plastic chrome cover.

**IMPORTANT: Before riding, bounce the front end of motorcycle and cycle the suspension to insure brake lines and horn *Do Not* contact the brace. It may be necessary to move or purchase after market brake lines and horn.**

---

#### MADE IN USA

SuperBrace is a registered trademark and is covered under one or more of the following patent numbers: 4,742,885 and/or 4,854,412.

#### 30 DAY GUARANTEE

If you are dissatisfied with your SuperBrace for any reason, please return it to us, postage paid within 30 days of the date of invoice. If the product has not been damaged or modified we will provide a full refund, No questions asked.