

SuperBrace

THE ULTIMATE FORK BRACE

SuperBrace Part # 3300

Installation instructions

Fits Model: Suzuki Cavalcade

Years: (Early 1986)

1. Place motorcycle on center stand.
2. Remove existing fork bridge.
3. Place SuperBrace squarely between the forks and press into place.

NOTE: The SuperBrace should fit snug, but DO NOT FORCE. If the SuperBrace will not seat by tapping with your hand, you may have to loosen the axle pinch bolts. Put the SuperBrace into position and then re-tighten the axle pinch bolts to factory specifications.

4. Torque bolts to factory specification.
5. Snap caps into bolt holes if caps apply.

IMPORTANT: Before riding, bounce the front end of motorcycle and cycle the suspension to insure brake lines and horn *Do Not* contact the brace. It may be necessary to move or purchase after market brake lines and horn.

MADE IN USA

SuperBrace is a registered trademark and is covered under one or more of the following patent numbers: 4,742,885 and/or 4,854,412.

30 DAY GUARANTEE

If you are dissatisfied with your SuperBrace for any reason, please return it to us, postage paid within 30 days of the date of invoice. If the product has not been damaged or modified we will provide a full refund, No questions asked.