

# SuperBrace

## THE ULTIMATE FORK BRACE

---

### SuperBrace Part # 3302

---

#### Installation instructions

**Fits Model: Suzuki DRZ 400 E / DRZ 400 S**

**Years: (2001-2007)**

1. Place motorcycle on center stand (Or side stand).
2. Push rubber boot up off lower fork.
3. Disassemble SuperBrace.
4. Loosen axle pinch bolts.
5. Assemble SuperBrace on lower fork leg over the seals. The brace is fabricated with a locating step on it. \*Note: make sure SuperBrace clears the tire. Due to the different tires used on the bike.
6. Torque SuperBrace bolts to 10 ft. pounds.
7. Push rubber boot down into SuperBrace locking it over the boot clip ring (if fork boots are too long, cut the top end to length and use a zip tie to fasten them down again).
8. Re-torque axle pinch bolts to factory specification.

**IMPORTANT: Before riding, bounce the front end of motorcycle and cycle the suspension to insure brake lines and horn *Do Not* contact the brace. It may be necessary to move or purchase after market brake lines and horn.**

---

#### MADE IN USA

SuperBrace is a registered trademark and is covered under one or more of the following patent numbers: 4,742,885 and/or 4,854,412.

#### 30 DAY GUARANTEE

If you are dissatisfied with your SuperBrace for any reason, please return it to us, postage paid within 30 days of the date of invoice. If the product has not been damaged or modified we will provide a full refund, No questions asked.

*www.superbrace.com*

*Phone (800) 322-4783 or Fax (714) 842-0866*