

# SuperBrace

## THE ULTIMATE FORK BRACE

---

### SuperBrace Part #5182

---

#### Installation instructions

**Fits Model: Harley-Davidson Sportster Narrow Glide, 35mm**

**Years: (1975-1987)**

1. Place motorcycle on center stand. If your motorcycle is not equipped with a center stand, place a block device under the side stand to get the motorcycle as upright as possible without it being over center.
2. Disassemble the SuperBrace.
3. Slide the rubber fork seal dust covers up the legs away from the seal area.
4. Loosen the axle caps or pinch bolts to allow the forks to relax.
5. Assemble the SuperBrace around the lower fork legs and over the top of the fork seal.
6. Torque the four stainless allen bolts to 10 ft. pounds.
7. Push down rubber dust covers to the brace and secure over boot clip ring.
8. Re-torque the axle caps or pinch bolts.

**IMPORTANT: Before riding, bounce the front end of motorcycle and cycle the suspension to insure brake lines and horn *Do Not* contact the brace. It may be necessary to move or purchase after market brake lines and horn.**

---

#### MADE IN USA

SuperBrace is a registered trademark and is covered under one or more of the following patent numbers: 4,742,885 and/or 4,854,412.

#### 30 DAY GUARANTEE

If you are dissatisfied with your SuperBrace for any reason, please return it to us, postage paid within 30 days of the date of invoice. If the product has not been damaged or modified we will provide a full refund, No questions asked.

[www.superbrace.com](http://www.superbrace.com)

Phone (800) 322-4783 or Fax (714) 842-0866