

SuperBrace

THE ULTIMATE FORK BRACE

SuperBrace Part #5183F

Installation instructions

Fits Model: Harley-Davidson Sportster Narrow Glide with Flames, 39mm

Years: (1988-2006)

1. Place motorcycle on center stand. If your motorcycle is not equipped with a center stand, place a block device under the side stand to get the motorcycle as upright as possible without it being over center.
2. Disassemble the SuperBrace.
3. Loosen the axle caps or pinch bolts to allow the forks to relax.
4. Loosely assemble the SuperBrace and make sure it is aligned properly around the forks. One half is mounted over the dust cover and the other half is on the lower fork leg. (Look inside the superbrace for a reference line)
5. Torque the four stainless bolts to 10 ft. pounds.
6. Re-torque axle caps or pinch bolts.

IMPORTANT: Before riding, bounce the front end of motorcycle and cycle the suspension to insure brake lines and horn *Do Not* contact the brace. It may be necessary to move or purchase after market brake lines and horn.

MADE IN USA

SuperBrace is a registered trademark and is covered under one or more of the following patent numbers: 4,742,885 and/or 4,854,412.

30 DAY GUARANTEE

If you are dissatisfied with your SuperBrace for any reason, please return it to us, postage paid within 30 days of the date of invoice. If the product has not been damaged or modified we will provide a full refund, No questions asked.

www.superbrace.com

Phone (800) 322-4783 or Fax (714) 842-0866